



# LauncherPlus


## User Manual

# Table of Contents

<b>The Device</b> .....	<b>1</b>
<b>Button Behavior</b> .....	<b>1</b>
When the LauncherPlus is connected but not projecting (Main button LED is solid red) .....	1
When the LauncherPlus is projecting (Main button LED is solid blue) .....	1
When the LauncherPlus is projecting to a quadrant (Corner button LED is solid blue).....	1
When the LauncherPlus is paused (Main button LED is solid red).....	2
<b>LED Behavior</b> .....	<b>2</b>
During the pairing process: .....	2
After Pairing: .....	2
<b>Installation (Pairing)</b> .....	<b>3</b>
<b>NovoConnect Device in Hotspot mode</b> .....	<b>3</b>
Via the NovoConnect Device's USB Port .....	3
Via your PC's USB Port .....	5
<b>NovoConnect Device in Wi-Fi mode</b> .....	<b>6</b>
Via the NovoConnect Device's USB Port .....	6
Via your PC's USB port .....	7
<b>NovoConnect Device with a Wired Connection</b> .....	<b>9</b>
Via the NovoConnect Device's USB Port .....	9
Via your PC's USB Port .....	11
<b>Usage</b> .....	<b>12</b>
<b>Additional Settings</b> .....	<b>14</b>
<b>Connection Settings</b> .....	<b>14</b>
<b>Password Lock</b> .....	<b>15</b>

# The Device

The LauncherPlus features a main button in the center of the device along with four corner buttons, all with corresponding LED indicators, whose behavior is described below.



## Button Behavior

### When the LauncherPlus is connected but not projecting (Main button LED is solid red)

Button	Action	Behavior
Main Button	Press	Starts projecting
Corner Buttons	N/A	N/A

### When the LauncherPlus is projecting (Main button LED is solid blue)

Button	Action	Behavior
Main Button	Press	Pauses projection (the NovoConnect device returns to the main screen)
	Press and hold for 3 seconds	Disconnects the LauncherPlus
Corner Buttons	Press	Projects the computer's screen onto the corresponding quadrant of the display

### When the LauncherPlus is projecting to a quadrant (Corner button LED is solid blue)

Button	Action	Behavior
Main Button	Press	Projects the computer's screen onto the display in full screen mode
	Press and hold for 3 seconds	Disconnects the LauncherPlus

<b>The Selected Corner Button</b>	Press	Pauses projection (the NovoConnect device returns to the main screen)
<b>An Unselected Corner Button</b>	Press	Switches projection of the computer's screen to the corresponding quadrant of the display

### When the LauncherPlus is paused (Main button LED is solid red)

Button	Action	Behavior
<b>Main Button</b>	Press	Projects the computer's screen onto the display in full screen mode
	Press and hold for 3 seconds	Disconnects the LauncherPlus
<b>Corner Buttons</b>	Press	Projects the computer's screen onto the corresponding quadrant of the display

## LED Behavior

### During the pairing process:

LED		Definition
Main Button LED	Corner Button LEDs	
Flashing Blue	(All) Flashing Blue	The LauncherPlus has been plugged into a PC.
Solid Red	N/A	The LauncherPlus has been paired to a NovoPro, but is not projecting.

### After Pairing:

LED		Definition
Main Button LED	Corner Button LEDs	
Solid Blue	N/A	The LauncherPlus is projecting in full screen mode
N/A	(Single) Solid Blue	The LauncherPlus is projecting in the corresponding button's quadrant
N/A	(Single) Flashing Blue	The LauncherPlus is switching projection mode
Solid Red	N/A	Projection is paused

# Installation (Pairing)

There are various ways to pair the LauncherPlus to a NovoConnect device based on the network setting of the NovoConnect device. The table below outlines the various settings and their respective pairing methods:

NovoConnect Device's Network Connection Type	Pairing Method
<b>Hotspot</b>	Via the NovoConnect device's USB Port
	Via the PC's USB Port
<b>Wi-Fi</b>	Via the NovoConnect device's USB Port
	Via the PC's USB Port
<b>Wired</b>	Via the NovoConnect device's USB Port
	Via the PC's USB Port


The sections below describe the instructions for each pairing method.

## NovoConnect Device in Hotspot mode


### Via the NovoConnect Device's USB Port

1. Connect the LauncherPlus to the NovoConnect device.


*NOTE: The NovoConnect device must be powered on and connected to a display.*



- The main button on the LauncherPlus lights up red and a **Loading...** screen is shown on the display.



- Wait for the main and corner buttons on the LauncherPlus to light up blue and the **Pairing Completed** screen to be shown on the display.




- The pairing process is complete. Proceed to the Usage section to begin using the LauncherPlus.


## Via your PC's USB Port

Before pairing via the PC's USB port, ensure that the PC features a working Wi-Fi connection with WEP, WPA/WPA2, or 802.1x encryption.

1. Connect the LauncherPlus to your PC's USB port. The LauncherPlus will check to see if its software package is already stored in the PC. If the software package is not stored in the PC, the PC will begin retrieving its software.



2. Once the software is ready, the LauncherPlus will begin scanning for NovoConnect devices.



3. A list of scanned NovoConnect devices will appear. Select the NovoConnect device you want to connect to from the list.




4. Once you have selected the NovoConnect device, the pairing process will be complete. Proceed to step #3 of the Usage section to begin using the LauncherPlus.

## NovoConnect Device in Wi-Fi mode

Before pairing, ensure that the NovoConnect device is powered on and features a working Wi-Fi connection with WEP, WPA/WPA2, or 802.1x encryption.


### Via the NovoConnect Device's USB Port

1. Connect the LauncherPlus to the NovoConnect device.




2. **For WEP, WPA/WPA2 Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi password. Enter the Wi-Fi password.

**For 802.1x Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi login and password. Enter the Wi-Fi login and password.



- Once you have entered the Wi-Fi connection login and/or password, wait for the main and corner buttons on the LauncherPlus to light up blue and the **Pairing Completed** screen to be shown on the display.

*NOTE: If a pairing failure prompt appears re-enter the login and/or password.*




- The pairing process is complete. Proceed to the Usage section to begin using the LauncherPlus.

## Via your PC's USB port

Before pairing via the PC, ensure that the PC features a working Wi-Fi connection with WEP, WPA/WPA2, or 802.1x encryption.

- Connect the LauncherPlus to your PC's USB port. The LauncherPlus will check to see if its software package is already stored in the PC. If the software package is not stored in the PC, the PC will begin retrieving its software.



2. Once the software is ready, the LauncherPlus will begin scanning for Wi-Fi connections.



3. A list of Wi-Fi connections will appear. Select the SSID of the Wi-Fi router which your NovoConnect device is connected to from the list.

**For WEP, WPA/WPA2 Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi password. Enter the Wi-Fi password.

**For 802.1x Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi login and password. Enter the Wi-Fi login and password.

*NOTE: If you are unable to find the SSID for the router you want to connect to select **Scan**.*




4. Once you have entered the correct password and/or login, the pairing process will be complete. Proceed to step #3 of the Usage section to begin using the LauncherPlus.

# NovoConnect Device with a Wired Connection


Before pairing ensure that the NovoConnect device is powered on and is connected via the LAN port to a router that features a working Wi-Fi connection with WEP, WPA/WPA2, or 802.1x encryption.

## Via the NovoConnect Device's USB Port

1. Connect the LauncherPlus to the NovoConnect device.




2. A pairing menu will appear. In the menu select the SSID of the network that the NovoConnect device is connected to.




- For WEP, WPA/WPA2 Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi password. Enter the Wi-Fi password.

**For 802.1x Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi login and password. Enter the Wi-Fi login and password.



- Once you have entered the Wi-Fi connection login and/or password, wait for the main and corner buttons on the LauncherPlus to light up blue and the **Pairing Completed** screen to be shown on the display.

*NOTE: If a pairing failure prompt appears re-enter the login and/or password.*




- The pairing process is complete. Proceed to the Usage section to begin using the LauncherPlus.


## Via your PC's USB Port

Before pairing via the PC, ensure that the PC features a working Wi-Fi connection with WEP, WPA/WPA2, or 802.1x encryption.

1. Connect the LauncherPlus to your PC's USB port. The LauncherPlus will check to see if its software package is already stored in the PC. If the software package is not stored in the PC, the PC will begin retrieving its software.



2. Once the software is ready, the LauncherPlus will begin scanning for Wi-Fi connections.



3. A list of Wi-Fi connections will appear. Select the SSID of the router which your NovoConnect device is connected to (via its LAN port) from the list.

**For WEP, WPA/WPA2 Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi password. Enter the Wi-Fi password.

**For 802.1x Wi-Fi Connections:** A prompt will appear asking for the Wi-Fi login and password. Enter the Wi-Fi login and password.

*NOTE: If you are unable to find the SSID for the router you want to connect to select **Scan**.*




4. Once you have entered the correct password and/or login, the pairing process will be complete. Proceed to step #3 of the Usage section to begin using the LauncherPlus.


## Usage

Follow the steps below to begin using the LauncherPlus.


1. **For First-Time Usage:** Connect the LauncherPlus to a computer and the LauncherPlus will begin retrieving its software package.  
**For Subsequent Usage:** Connect the LauncherPlus to a computer and the Novo software will run automatically.



2. Once the software is ready, the LauncherPlus will begin scanning for the NovoConnect device.



3. After the LauncherPlus has found the NovoConnect device, the main button on the LauncherPlus lights up red. Press the button to begin presenting.



4. Your computer's screen is shown on the display.



5. Press any corner button on the LauncherPlus to project your computer's screen onto the corresponding quadrant of the display, the button's blue LED will light when it is in use.



# Additional Settings

Once you have already paired your LauncherPlus with a NovoPro device, additional settings for your LauncherPlus can be configured from the Novo software, including pairing settings and a password lock.


## Connection Settings

To configure the pairing settings for your LauncherPlus:


1. Connect your LauncherPlus to a computer so that the Novo software launches.



2. Click the options menu (☰) and select **Configure LauncherPlus**.



3. Select **Edit** in the LauncherPlus settings menu.




4. Continue with steps 3 - 4 in the *Manual Pairing* section.


## Password Lock

You may configure your LauncherPlus with a password lock to prevent users from changing settings for the device. To create a password lock for your LauncherPlus:


1. Connect your LauncherPlus to a computer so that the Novo software launches.




2. Click the options menu (☰) and select **Configure LauncherPlus**.




3. Select **Lock** in the LauncherPlus settings menu.



4. Select Enable protection in the LauncherPlus Settings Protection window.



5. Enter the password you want to set for your Launcher Plus, confirm the password, and then select **Save**.



Once a password lock is set for your LauncherPlus, the password will need to be entered anytime a user wants to manually pair the LauncherPlus.

For more information on the other setting items in the Novo software options menu, please consult your NovoPro user manual.



### **Vivitek Europe**

Zandsteen 15, 2132 MZ Hoofddorp

The Netherlands

T: +31-20-800-3960

F: +31-20-655-0999

[www.vivitek.eu](http://www.vivitek.eu)

### **Vivitek Americas**

46101 Fremont Blvd, Fremont, CA 94538

U.S.A.

T: +1-510-668-5100

F: +1-510-668-0680

### **Vivitek Asia**

7F, No. 186, Ruey Kuang Road, Neihu, Taipei 11491

Taiwan R.O.C.

T: +886-2-8797-2088

F: +886-2-6600-2358